

**SHURE**

# ULX-D Dual and Quad

## Wireless Microphone System

Manual for the Shure ULXD Dual and Quad wireless system, including ULXD4D, ULXD4Q, ULXD1, and ULXD2. Find specifications, networking information, and more.

Version: 8.3 (2025-J)

# Table of Contents

<b>ULX-D Dual and Quad Wireless Microphone System</b>	<b>4</b>	Installing the Battery Contact Cover	37
<b>General Description</b>	<b>4</b>	<b>Setting Receiver Gain</b>	<b>37</b>
ULXD4D and ULXD4Q Receivers	4	Receiver Gain Controls	37
Answers to Common Questions	5	Reading the Audio Meter	38
<b>Quickstart Instructions</b>	<b>5</b>	Muting a Receiver Channel Audio Output	38
<b>Hardware Interface</b>	<b>7</b>	Transmitter Input Clip	38
Receiver	7	Audio Summing	39
Receiver Home Screen	9	Receiver Output Level	40
Transmitters	10	<b>RF</b>	<b>40</b>
Boundary and Gooseneck Base Transmitters	11	Transmitter RF Power	40
Advanced Transmitter Features	12	Interference Detection	40
Lock and Unlock ULX-D Receivers and Transmitters	13	High Density Mode	41
Home Screen Display Options	14	Frequency Diversity	41
Menu Screens	16	Setting Regional TV Format	42
<b>Scan and Sync</b>	<b>22</b>	Custom Groups	42
Multiple System Setup	23	Audio Signal Encryption	43
Manual Frequency Selection	24	RF Cascade Ports	43
Transmitter IR Presets	24	Antenna Bias	44
<b>Mixed-Band Operation</b>	<b>25</b>	<b>Networking ULX-D Receivers</b>	<b>44</b>
Compatible Groups by Band	25	Network Control Software	44
<b>Update ULXD Firmware</b>	<b>34</b>	IP Address Configuration	45
Firmware Versions	34	Networking Acronyms	45
Update the Receiver	35	Overview of Dante Network Modes	46
Update the Transmitter	35	Network Connection and Configuration Examples	47
<b>Batteries</b>	<b>35</b>	Assigning Network Device IDs for Shure Control and	
Battery Runtime Charts	36	Dante Control	52
Shure SB900 Series Rechargeable Battery	36	Route Audio with Dante Controller	53
Important Tips for Care and Storage of Shure Rechargeable Batteries	37	Network Troubleshooting	54
		Restoring Dante Factory Settings	54
		<b>System Reset</b>	<b>55</b>
		<b>Connecting to an External Control System</b>	<b>55</b>

---

Setting the Gateway to Allow Cross Subnet Routing	55	<b>Specifications</b>	<b>61</b>
		ULXD4D & ULXD4Q	63
<b>Shure Wireless Coordination and Management Tools</b>	<b>55</b>	ULXD1	64
Wireless Workbench	56	ULXD2	66
Wireless Workbench Mobile	56	Tables and Diagrams	67
<b>Troubleshooting</b>	<b>56</b>	Batteries	68
Power	57	Frequency Range and Transmitter Output Power	68
Cables	57		
Encryption Mismatch	57	<b>Safety and Regulatory Information for Wireless Products</b>	<b>76</b>
Radio Frequency (RF)	57	Explanation of Symbols	76
<b>Contact Customer Support</b>	<b>58</b>	Important Safety Instructions	76
		Safety Information for Batteries	77
<b>Included Components</b>	<b>58</b>		
All Systems	58	<b>Regulatory Information for Class B EMC Products</b>	<b>78</b>
Handheld Systems	59		
Bodypack System	59	<b>Environmental Regulatory Information</b>	<b>82</b>
Antennas	60	中国 RoHS	83
<b>Optional Accessories</b>	<b>60</b>	<b>Certifications</b>	<b>83</b>
		ULXD1, ULXD2	83

# ULX-D Dual and Quad Wireless Microphone System

## General Description

Shure ULX-D™ Digital Wireless offers uncompromising 24-bit audio quality and RF performance, with intelligent, encryption-enabled hardware, flexible receiver options, and advanced rechargeability options for professional sound reinforcement.

A breakthrough in wireless audio quality, Shure digital processing enables ULX-D to deliver the purest reproduction of source material ever available in a wireless system, with a wide selection of trusted Shure microphones to choose from. Extended 20 Hz – 20 kHz frequency range and flat response captures every detail with clarity, presence, and incredibly accurate low end and transient response. With greater than 120 dB, ULX-D delivers wide dynamic range for excellent signal-to-noise performance. Optimized for any input source, ULX-D eliminates the need for transmitter gain adjustments.

ULX-D sets a new and unprecedented standard for spectral efficiency and signal stability. The intermodulation performance of ULX-D is an incredible advancement in wireless performance, enabling a dramatic increase in the number of simultaneous active transmitters on one TV channel. Rock-solid RF signal with zero audio artifacts extends over the entire range. For applications where secure wireless transmission is required, ULX-D offers Advanced Encryption Standard (AES) 256-bit encrypted signal for unbreakable privacy.

For scalability and modular flexibility, ULX-D receivers come in single, dual, and even quad channel versions. The dual and quad channel receivers offer conveniences such as RF cascade, internal power supply, bodypack frequency diversity, audio output channel summing, and Dante™ digital networking for multi-channel audio over Ethernet. All receivers offer High-Density mode for applications where high channel counts are needed, greatly increasing the amount of simultaneous channels possible over one frequency band.


Advanced Lithium-ion rechargeability provides extended transmitter battery life over alkaline batteries, battery life metering in hours and minutes accurate to within 15 minutes, and detailed tracking of battery health status.

Generations ahead of any other available system in its class, ULX-D brings a new level of performance to professional sound reinforcement.

## ULXD4 and ULXD4Q Receivers


The ULXD4 receiver is available in dual channel and quad channel models. Both models share the same feature set and functionality, but differ in the number of channels available and the number of audio outputs.

The descriptions and procedures in this guide are applicable to either the dual or the quad receiver.



**ULXD4 Dual Receiver**

*Supports 2 channels of wireless audio.*







**ULXD4Q Quad Receiver**

*Supports 4 channels of wireless audio.*

## Answers to Common Questions

- How to use wide tuning receivers and transmitters with legacy devices: [Mixed-Band Operation](#)
- Using a ULX-D wide tuning receiver with a QLX-D transmitter: [ULX-D Wide Tuning with QLX-D FAQ](#)
- QLX-D and ULX-D cross compatibility: [Will a QLXD Transmitter work with a ULX-D Receiver and vice versa? FAQ](#)
- How to [update ULX-D firmware](#)
- Enable or disable [access control](#) on ULX-D
- How to [unlock ULXD1 and ULXD2](#)

# Quickstart Instructions




How to set up ULX-D:

1. Attach antennas, connect receiver to power, and plug in to mixer or amplifier.
2. Scan for and deploy frequencies.
3. Insert batteries into transmitters (Shure SB900-series rechargeable or AAs) and power on.
4. Sync transmitters to receiver channels.

# Hardware Interface

## Receiver

### Front Panel



#### ① Infrared (IR) Sync Window

Sends IR signal to the transmitter for sync.

#### ② Network Icon

Illuminates when the receiver is connected with other Shure devices on the network. IP address must be valid to enable networked control.

#### ③ Encryption Icon

Illuminates when AES-256 encryption is activated.

#### ④ LCD Panel

Displays settings and parameters.

#### ⑤ Scan Button

Press to find the best channel or group.

#### ⑥ Menu Navigation Buttons

Use to navigate and select parameter menus.

#### ⑦ Control Wheel

- Push to select a channel or menu item
- Turn to scroll through menu items or to edit a parameter value

#### ⑧ Channel Select Button

Press to select a channel.

#### ⑨ Sync Button

Press the sync button while the receiver and transmitter IR windows are aligned to transfer settings from the receiver to the transmitter.

#### ⑩ RF Diversity LEDs

Indicate antenna status:

- Blue = normal RF signal between the receiver and transmitter
- Red = interference detected
- Off = No RF connection between the receiver and transmitter

*Note: the receiver will not output audio unless one blue LED is illuminated.*

## ⑪ RF Signal Strength LEDs

Indicate the RF signal strength from the transmitter:

- Amber = Normal (-90 to -70 dBm)
- Red = Overload (greater than -25 dBm)

## ⑫ Audio LEDs

Indicate average and peak audio levels:

LED	Audio Signal Level	Description
Red (6)	-0.1 dBFS	Overload/ limiter
Yellow (5)	-6 dBFS	Normal peaks
Yellow (4)	-12 dBFS	
Green (3)	-20 dBFS	
Green (2)	-30 dBFS	Signal Present
Green (1)	-40 dBFS	

*Note: In Frequency Diversity mode, simultaneous blinking of the red and yellow audio LEDs indicates that diversity audio has been routed to this channel.*


## ⑬ Gain Buttons

Press the ▲ ▼ gain buttons on the front of the receiver to incrementally adjust gain from -18 to +42 dB.

## ⑭ Power Switch

Powers the unit on or off.

## Back Panel



## ① AC Power Input

IEC Connector, 100 - 240 V AC.

## ② RF Antenna Diversity Input Jack (2)

For antenna A and antenna B.

### ③ RF Cascade Jack (2)

Passes the RF signal from Antenna A and Antenna B to one additional receiver.

### ④ Mic/Line Switch (one per channel)

Applies a 30 dB pad in mic position.

### ⑤ Balanced XLR Audio Output (one per channel)

Connect to a mic or line level input.

### ⑥ Network Status LED (Green)

One per network port.

- Off = no link
- On = network link
- Flashing = network link active

### ⑦ Ethernet/Dante Network Secondary Port

Connect to an Ethernet network to enable remote device control via Wireless Workbench software. Also carries Dante digital audio and control signals for audio distribution, monitoring, and recording - see Dante Network topic.

### ⑧ Network Speed LED (Amber)

One per network port.

- Off = 10/100 Mbps
- On = 1 Gbps

### ⑨ Ethernet/Dante Network Primary Port


Connect to an Ethernet network to enable remote device control via Wireless Workbench. Also carries Dante digital audio and control signals for audio distribution, monitoring, and recording - see Dante Network topic.

## Receiver Home Screen

The home screen displays the following information for each receiver channel:

- Group and Channel
- Transmitter Status: NoTx or TxOn, battery icon/remaining battery life

Press the SEL button to access a channel menu screen.



# Transmitters

## ① Power LED

- Green = unit is powered on
- Red = low battery or battery error (see Troubleshooting)
- Amber = power switch is disabled

## ② On/Off Switch

Powers the unit on or off.

## ③ SMA Connector

Connection point for RF antenna.

## ④ LCD Display:

View menu screens and settings. Press any control button to activate the backlight.

## ⑤ Infrared (IR) Port

Align with the receiver IR port during an IR sync for automated transmitter programming.

## ⑥ Menu Navigation Buttons

Use to move through parameter menus and change values.

exit	Acts as a 'back' button to return to previous menus or parameters without confirming a value change
enter	Enters menu screens and confirms parameter changes
▼ ▲	Use to scroll through menu screens and to change parameter values

## ⑦ Battery Compartment

Requires Shure rechargeable battery or 2 AA batteries.

## ⑧ AA Battery Adapter

- Handheld: rotate and store in the battery compartment to use a Shure rechargeable battery
- Bodypack: remove to accommodate a Shure rechargeable battery

## ⑨ Bodypack Antenna

For RF signal transmission.

## ⑩ Integrated Antenna


For RF signal transmission.

## ⑪ Microphone Cartridge

See Optional Accessories for a list of compatible cartridges.

## ⑫ TA4M / LEMO Input Jack


Connects to a microphone or instrument cable.



## Installing Bodypack Antennas

Hand-tighten antennas until secure. Do not use tools.

## Boundary and Gooseneck Base Transmitters



## ① Power Button

Press to power on; press and hold to power off.

## ② Mute/Active Button

Four settings are available for the mute/active button:

- Toggle: Press to switch between active and mute states
- Push-to-Mute: Hold button to mute microphone
- Push-to-Talk: Hold button to activate microphone
- Disabled: Button functionality off

## ③ Mute LED

Indicates whether microphone is active or muted. The following settings are available:

Active	Muted
Green*	Red*
Red	Off
Red	Flashing red

\*MX400R series gooseneck microphones (red LED) do not offer this setting.

## ④ Low-Battery LED

- Off = More than 30 minutes of battery life remain
- On (red) = Less than 30 minutes of battery life remain
- On (green) = Microphone docked on charging station
- On (amber) = Battery is missing or is not inserted correctly

## ⑤ Infrared (IR) Port

Align with receiver IR port to send settings to transmitter.

## ⑥ Charge Connector

Connects to networked chargers and USB power supply.

## ⑦ Gooseneck Microphone

ULXD8 base fits 5", 10", and 15" Microflex series microphones, available in single or dualflex and with bi-color or red-only LEDs.

# Advanced Transmitter Features

## RF MUTE

Use this to turn on a transmitter without interfering with the RF spectrum.

Press and hold exit during power-on until RF MUTED is displayed. To un-mute, restart the transmitter.



## MIC.OFFSET

MIC.OFFSET compensates for signal level differences between transmitters that share the same receiver channel.

Set the offset gain on a low signal level transmitter to match a louder transmitter: **UTILITY > MIC.OFFSET**

**Note:** For normal gain adjustments, use the receiver gain buttons.

## Transmitter Audio Mute Mode

Mute Mode reconfigures the transmitter power switch to act a mute switch for the audio. Using the switch, the audio can be easily turned on or muted by presenters, sports referees, or anyone who periodically needs to speak. When the audio is muted, the transmitter RF signal remains on and ready at all times.

**Note:** Mute Mode can be selected as an IR PRESET option.

To set a transmitter to Mute Mode:

1. From the transmitter menu: **UTILITY > MUTE MODE**
2. Use the arrows to select ON or OFF.
3. Press enter to save.

**Tip:** The transmitter LED turns red when audio is muted and turns green when audio is enabled. The display of the transmitter will show AUDIO MUTED and the receiver display will show Tx Muted.

**Note:** Mute Mode must be set to OFF in order to use the power switch to turn off the transmitter.

## Lock and Unlock ULX-D Receivers and Transmitters

Use the LOCK feature to prevent accidental or unauthorized changes to the hardware.

### Receivers (ULXD4D and ULXD4Q)

Menu path: **DEVICE UTILITIES > LOCK**

Use the control wheel to select and lock any of the following receiver functions.

- MENU: All menu paths are inaccessible
- GAIN: Front panel gain button is disabled
- POWER: Power switch is disabled
- SCAN: Front panel SCAN button is disabled and prevents frequency changes due to group scans initiated by other ULXD units
- SYNC: Front panel SYNC button is disabled

**Tip:** To unlock, press EXIT, turn the control wheel to select UNLOCKED, and press ENTER to save.

### Transmitters (ULXD1 and ULXD1)

Menu path: **UTILITY > LOCK**

Use the transmitter controls to select and lock any of the following transmitter functions.

- MENU LOCK: All menu paths are inaccessible.
- POWER LOCK: Power switch is disabled

**Quick-Lock option:** To turn on the transmitter with its power and menu navigation buttons locked, press and hold the ▲ button during power-on until the locked message is displayed.

**Tip:** To unlock the MENU LOCK, press the ENTER button 4 times to pass through the following screens: UTILITY > LOCK > MENU UNLOCK

To unlock the POWER LOCK, set the power switch to the off position, then press and hold the ▲ button while resetting the power switch to the on position.

## Home Screen Display Options

### Receiver

The HOME INFO menu provides options to change the information shown on the receiver home screen:

DEVICE UTILITIES > HOME INFO

Use the control wheel to select one of the following screen displays.



CHANNAME  
470.150MHz      8:37  
+10dB      ULXD1

Receiver home screen view 1



470.150MHz  
G:01 CH:01  
GAIN: +0dB      No Tx

Receiver home screen view 2



G:01 CH:01  
470.150MHz      8:37  
GAIN: +0dB      ULXD1

Receiver home screen view 3

## Transmitter

**Home Screen:** Press the **▲ ▼** arrows at the home menu to display one of the following screens:



Transmitter home screen view 1




Transmitter home screen view 2



Transmitter home screen view 3

# Menu Screens

## Receiver Channel



### ① Receiver Information

Use DEVICE UTILITIES > HOME INFO to change the home screen display.

### ② Gain Setting

-18 to +42 dB, or Mute.

### ③ Mic. Offset Indicator

Indicates offset gain is added to the transmitter.

### ④ Transmitter Settings

The following information cycles when a transmitter is tuned to the receiver's frequency:

- Transmitter Type
- Input Pad (Bodypack only)
- RF Power Level
- Transmitter Lock Status
- Transmitter Mute Status

### ⑤ Battery Runtime Indicator

Shure rechargeable battery: runtime is displayed in minutes remaining.

AA batteries: runtime is displayed with a 5-bar indicator.

### ⑥ TV Channel

Displays the TV channel that contains the tuned frequency.

### ⑦ High Density Mode Icon


Displayed when High Density mode is enabled.

## Transmitter Status

The following text or icons report transmitter status to the receiver screen:

Display Icon	Transmitter Status
■	Bodypack input is attenuated 12 dB
*	Offset gain is added to the transmitter
Lo	1 mW RF power level
Nm	10 mW RF power level
Hi	20 mW RF power level
M	Menu is locked
P	Power is locked
<b>TxMuted</b>	Displayed when the transmitter audio is set to off using the MUTE MODE feature
<b>-No Tx-</b>	No RF connection between a receiver and transmitter or transmitter OFF

## Transmitter



### ① Transmitter Information

Scroll ▲ ▼ at the home screen to change the display

### ② Power Lock Indicator

Indicates power switch is disabled

### ③ Transmitter Audio Muted Indicator

Displayed when the transmitter audio is set to off using the MUTE MODE feature.

### ④ Battery Runtime Indicator

- Shure rechargeable battery: runtime is displayed in hours:minutes remaining
- AA Batteries: runtime is displayed with a 5-bar indicator

### ⑤ Menu Lock Indicator

Indicates menu navigation buttons are disabled

**⑥ Mic. Offset**

Displays microphone offset gain value

**⑦ RF Power**

Displays RF power setting

**⑧ Bodypack Input Pad**

The input signal is attenuated 12 dB

**⑨ Encryption Icon**

Indicates encryption is enabled on the receiver and has been transferred to the transmitter from a sync

## Adjusting Receiver Display Brightness and Contrast

Adjust BRIGHTNESS and CONTRAST settings to improve visibility in challenging lighting environments.

1. From the receiver menu: DEVICE UTILITIES > DISPLAY
2. Press the control wheel to select CONTRAST or BRIGHTNESS.
3. Turn the control to adjust the selected parameter.
4. Press ENTER to save changes.

## Editing Receiver Channel Name

To edit a receiver channel name, choose EDIT NAME from the menu.

- Turn the control wheel to edit a highlighted character
- Press the control wheel to advance to the next character
- Press ENTER to save changes

**Note:** The channel name is transferred to a transmitter during a sync.

## Receiver Menu Descriptions

### RADIO

Displays Group, Channel, Frequency, and TV information. Use the control wheel to edit values

**G:**

Group for the selected frequency

**CH:**

Channel for the selected frequency

**FREQUENCY**

Selected frequency (MHz)

**TV:**

Displays the TV channel for the selected frequency

## AUDIO

### GAIN

Use the control wheel or gain buttons to adjust the channel gain from -18 to 42 dB, in 1 dB increments.

### MUTE

Mutes the receiver audio output.

## EDIT NAME

Use the control wheel to assign and edit the selected receiver channel name.

## IR PRESETS

## BODYPACK / HANDHELD

### BP PAD

Sets the audio input attenuation options: KEEP, 0, -12.

### LOCK

Sets the lock options: KEEP, Power, Menu, All, None

### RF POWER

Sets the transmitter RF power level: KEEP, 10mW=Nm, 1mW=Lo, 20mW=Hi.

### BATT

Sets the transmitter battery type to ensure accurate metering: KEEP, Alkaline, NiMH, Lithium

### BP OFFSET

Adjustable gain to compensate for signal level difference between transmitters: KEEP, 0 to 21 dB in 3 dB increments

### HH OFFSET

Adjustable gain to compensate for signal level difference between transmitters: KEEP, 0 to 21 dB in 3 dB increments

### MUTE MODE

Configures the transmitter power switch to act as an audio mute switch.

### Cust. Group

Create Custom Groups of up to 6 frequencies and export to networked receivers

## GOOSENECK / BOUNDARY

### HIGH PASS

Attenuates frequencies below 150 Hz by 12 dB per octave: KEEP, OFF, ON

### RF POWER

---

Sets the transmitter RF power level: KEEP, 10mW=Nm, 1mW=Lo, 20mW=Hi

## **BATTERY**

Sets the transmitter battery type to ensure accurate metering: KEEP, Alkaline, NiMH, Lithium

## **BN OFFSET**

Adjustable gain to compensate for signal level difference between transmitters: KEEP, 0 to 21 dB in 3 dB increments

## **GN OFFSET**

Adjustable gain to compensate for signal level difference between transmitters: KEEP, 0 to 21 dB in 3 dB increments

## **POWER LOCK**

Locks the transmitter's power button: KEEP, OFF, ON

## **Cust. Group**

Create Custom Groups of up to 6 frequencies and export to networked receivers

## **INITIAL STATE FROM CHARGER**

Choose the transmitter's state after it is removed from a charger: KEEP, Active, Muted, OFF

## **MUTE BUTTON BEHAVIOR**

Sets the mute button behavior: KEEP, Toggle, Push-to-Talk, Push-to-Mute, Disabled

## **BN MUTE LED ACTIVE/MUTE**

Sets the mute LED colors for active and muted states: KEEP, Green/Red, Red/OFF, Red/Flash-Red, OFF/OFF

## **GN MUTE LED ACTIVE/MUTE**

Sets the mute LED colors for active and muted states: KEEP, Green/Red, Red/OFF, Red/Flash-Red, OFF/OFF

## **MUTE LED LIGHT BRIGHTNESS**

Sets the mute LED brightness: KEEP, Normal, Low

## **BATTERY INFO**

## **HEALTH**

Percentage of charge capacity compared to a new battery

## **CHARGE**

Percentage of charge capacity

## **CYCLES**

Number of charge cycles logged by the battery

## **TEMP**

Battery temperature: °C/°F

## DEVICE UTILITIES

### FREQ DIVERSITY

- OFF (default)
- 1 + 2
- 3 + 4 (quad only)
- 1 + 2 / 3 + 4 (quad only)

### AUDIO SUMMING

- OFF (default)
- 1 + 2
- 3 + 4 (quad only)
- 1 + 2 / 3 + 4 (quad only)
- 1 + 2 + 3 + 4 (quad only)

### ENCRYPTION

Set encryption: ON/OFF

**Note:** For some units, encryption cannot be turned off.

### ADVANCED RF

- HIGH DENSITY: ON/OFF
- CUSTOM GROUPS: SETUP/EXPORT/CLEAR
- ANTENNA BIAS: ON/OFF
- SWITCH BAND (Japan AB band only)

### LOCK

- MENU: LOCKED/UNLOCKED
- GAIN: LOCKED/UNLOCKED
- POWER: LOCKED/UNLOCKED
- SCAN: LOCKED/UNLOCKED
- SYNC: LOCKED/UNLOCKED

### HOME INFO

Select screen options for Home Menu.

### DISPLAY

- CONTRAST
- BRIGHTNESS: LOW/MEDIUM/HIGH

### NETWORK

- CONFIGURATION: SWITCHED/REDUNDANT AUDIO/SPLIT
- SHURE CONTROL: DEVICE ID, Network Mode, Set IP and Subnet values for Ethernet network, Disable access control. To enable access control or learn more, refer to [Access Control](#) in the Wireless Workbench help system.
- DANTE: DANTE DEVICE ID, AUDIO & CNTRL, REDUNDANT AUDIO, Set IP, Subnet, Gateway and Yamaha values for Dante™ network, DANTE DEVICE LOCK, DDM

**Note:** Additional information can be accessed from the selected networking option.

## TX FW UPDATE

IR DOWNLOAD, Tx Firmware Version

## SYSTEM RESET

- RESTORE: Default Settings, Presets
- SAVE: Create New Preset
- DELETE: Delete Preset

## VERSION

- Model
- Band
- S/N (serial number)
- Ver
- Mcu
- FPGA
- Boot

## DANTE VERSIONS

- REV
- FW
- HW
- BOOT
- USER
- CAP

# Scan and Sync

Use this procedure to tune a receiver and transmitter to the best open channel.

**Note:** If you're using transmitters and receivers with mixed bands, such as a wide tuning receiver and a legacy transmitter, see [Mixed Band Operation](#) for instructions.

**Important!** Before you begin:

**Turn off** all transmitters to prevent them from interfering with the frequency scan.


**Turn on** any devices that might produce interference during the show so the scan can detect and avoid them, including:

- Other wireless systems or devices
- Computers
- Large LED panels
- Effects processors

1. Press SEL to select a receiver channel.
2. Perform a group scan on the receiver: SCAN > GROUP SCAN.
3. Press SCAN. While the scan is running, SCANNING appears on the screen.
4. When the scan is done, the receiver displays the group with the most available frequencies. Press the flashing ENTER button to deploy frequencies to each receiver channel.

5. Power on the ULXD transmitter.
6. Press the sync button on the receiver.
7. Align the IR windows until the receiver IR port turns red.

**Note:** When complete, SYNC SUCCESS! appears. The transmitter and receiver are now tuned to the same frequency.



## Multiple System Setup

A setup using networked receivers is the fastest and easiest way to distribute the best open channel to each system. See Networking ULX-D Receivers for networking details.

**Note:** Networked receivers must all be within the same frequency band.

## Networked Receivers

1. Turn on all receivers.
2. Conduct a group scan on the first receiver to find available frequencies in each group: SCAN > GROUP SCAN.
3. Press ENTER to accept the group number and automatically assign the next best channel to each receiver on the network. The receiver LEDs will flash when a frequency has been assigned.
4. Turn on a transmitter and sync to the receiver.

**Important!** Leave the transmitter on and repeat this step for each additional system.

## Non-networked Receivers

1. Turn on all receivers.
2. Conduct a group scan on the first receiver to find available frequencies in each group: SCAN > SCAN > GROUP SCAN > SCAN
3. When the scan is complete, use the control wheel to scroll through each group. Press ENTER to select a group that has enough available frequencies for all channels in the system.
4. Sync a transmitter to each receiver channel.

**Important!** Leave all transmitters on use the following steps to set up additional receiver channels:

1. Set each additional receiver channel to the same group as the first receiver: RADIO > G :
2. Conduct a channel scan to find available frequencies within the group: SCAN > SCAN > CHANNEL SCAN > SCAN
3. When the scan is complete, press ENTER to assign frequencies to each receiver channel.
4. Sync a transmitter to each receiver channel.

## Manual Frequency Selection

To manually adjust group, channel, or frequency:

1. Press SEL to choose a receiver channel and navigate to the RADIO menu.
2. Use the control wheel to adjust the group, channel, or frequency.
3. Press ENTER to save changes.

## Transmitter IR Presets

Use the IR PRESETS receiver menu to quickly configure transmitter settings from the receiver screen. When a sync is performed between the receiver and transmitter, the IR PRESETS automatically configure the transmitter. Each parameter has the default value KEEP, which leaves that setting unaffected by a sync.

Feature	Setting
<b>BP PAD</b>	+0 dB, -12 dB
<b>LOCK</b>	Power, Menu, All, None
<b>RF POWER</b>	10mW=Nm (normal), 1mW=Lo (low), 20mW=Hi (high)
<b>BATT</b>	Alkaline, NiMH, Lithium
<b>BP OFFSET</b>	0 dB to +21 dB (in 3 dB increments)
<b>HH OFFSET</b>	0 dB to +21 dB (in 3 dB increments)
<b>MUTE MODE</b>	OFF, ON
<b>Cust. Group</b>	OFF, ON

**Note:** When Cust. Groups is set to on, it may take up to 30 seconds to complete an IR sync.

## Creating a System Preset

System Presets allow a current receiver setup to be saved and restored. Presets store all receiver settings to provide a quick way to configure a receiver or switch between several different setups. Up to 4 presets can be stored in receiver memory.

To save the current receiver setup as a new preset: DEVICE UTILITIES > SYSTEM RESET > SAVE > CREATE NEW PRESET

Use the control wheel to name the preset, and then press Enter to save.

To recall a saved preset: DEVICE UTILITIES > SYSTEM RESET > RESTORE

Use the control wheel to select the preset name, and then press Enter.

## Mixed-Band Operation

As long as ULX-D transmitters and receivers can be tuned to the same frequency, they can be used together. Mixed-band operation is necessary in order to use wide tuning ULX-D transmitters and receivers with legacy ULX-D transmitters and receivers.

To sync legacy and wide tuning devices, follow these steps to tune them to different, but compatible, bands:

1. Press SCAN on the front of the receiver twice.
2. Choose Channel Scan or Group Scan.
  - If using channel scan: Refer to the tables below to select the group that is compatible with your transmitter band. Press ENTER to complete the scan.
  - If using group scan: After the scan is complete, refer to the tables below and select the group that is compatible with your transmitter band.
3. Press ENTER to deploy frequencies to each receiver channel.
4. Power on the ULXD transmitter.
5. Press the sync button on the receiver.
6. Align the IR windows until the receiver IR port turns red. When complete, SYNC DONE! appears. The transmitter and receiver are now tuned to the same frequency.

**Note:** The transmitter may indicate "G:-- Ch:--" because the 2 RF bands do not share the exact same group-channel map, but the frequency will match and the devices will work together.

## Compatible Groups by Band

### G54 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
G52	06
	07
	08
H52	09
	10
	11

### G54 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G54 HD	AA

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G52 HD	AB
H52 HD	AC
TV22	AD
TV23	AE
TV24	AF
TV25	AG
TV26	AH
TV27	AI
TV28	AJ
TV29	AK
TV30	AL
TV31	AM
TV32	AN

## G55 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
G50	06
	07
	08
H50	09
	10
	11
J50, without TV37	12
	13
	14

## G55 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G55 HD, no TV37	AA
G50 HD	AB
H50 HD	AC
J50 HD, no TV37	AD
TV14	AE
TV15	AF
TV16	AG
TV17	AH
TV18	AI
TV19	AJ
TV20	AK
TV21	AL
TV22	AM
TV23	AN
TV24	AO
TV25	AP
TV26	AQ
TV27	AR
TV28	AS
TV29	AT
TV30	AU
TV31	AV
TV32	AW
TV33	AX
TV34	AY
TV35	AZ
TV36	BA

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV38	BB
TV39	BC
TV40	BD
TV41	BE

## G56 Receiver - Standard Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G51	06
	07
	08
H51	09
	10
	11
UK TV38 with 500 kHz guard band	12
Belgium 1 TV27+29 w/100 kHz guard band max channels	13
Belgium 2 TV27+29 w/100 kHz guard band standard	14
Belgium 3 TV27+29 w/100 kHz guard band robust	15
EU except UK no TV38 with 100 kHz guard band max channels	16
EU except UK no TV38 with 100 kHz guard band standard	17

## G56 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G56 HD	AA
G51 HD	AB
H51 HD	AC
TV21	AD
TV22	AE
TV23	AF

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV24	AG
TV25	AH
TV26	AI
TV27	AJ
TV28	AK
TV29	AL
TV30	AM
TV31	AN
TV32	AO
TV33	AP
TV34	AQ
TV35	AR
TV36	AS
TV37	AT
TV38	AU
TV39	AV
TV40	AW
TV41	AX

## G57 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
G50	06
	07
	08
H50	09
	10
	11
J50A	12
	13

Legacy Band	Group on Wide Tuning Receiver
	14

## G57 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G57 HD	AA
G50 HD	AB
H50 HD	AC
J50A HD	AD
TV14	AE
TV15	AF
TV16	AG
TV17	AH
TV18	AI
TV19	AJ
TV20	AK
TV21	AL
TV22	AM
TV23	AN
TV24	AO
TV25	AP
TV26	AQ
TV27	AR
TV28	AS
TV29	AT
TV30	AU
TV31	AV
TV32	AW
TV33	AX
TV34	AY

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV35	AZ
TV36	BA

## G65 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
G51	06
	07
	08
H51	09
	10
	11

## G65 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G56 HD	AA
G51 HD	AB
H51 HD	AC
TV21	AD
TV22	AE
TV23	AF
TV24	AG
TV25	AH
TV26	AI
TV27	AJ
TV28	AK
TV29	AL
TV30	AM
TV31	AN

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV32	AO
TV33	AP
TV34	AQ
TV35	AR
TV36	AS
TV37	AT

### G66 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
G51	06
	07
	08
G52	09
	10
	11
H51	12
	13
	14

### G66 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
G66 HD	AA
G51 HD	AB
G52 HD	AC
H51 HD	AD
TV23	AE
TV24	AF
TV25	AG

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV26	AH
TV27	AI
TV28	AJ
TV29	AK
TV30	AL
TV31	AM
TV32	AN
TV33	AO
TV34	AP
TV35	AQ
TV36	AR
TV37	AS

## H54 Receiver - Standard Mode

Legacy Band	Group on Wide Tuning Receiver
	06
H51	07
	08
	09
L51	10
	11

## H54 Receiver - HD Mode

Legacy/TV Channel Band	Group on Wide Tuning Receiver
H54 HD	AA
H51 HD	AB
L51 HD	AC
TV27	AD

Legacy/TV Channel Band	Group on Wide Tuning Receiver
TV28	AE
TV29	AF
TV30	AG
TV31	AH
TV32	AI
TV33	AJ
TV34	AK
TV35	AL
TV36	AM
TV37	AN
TV38	AO
TV39	AP
TV40	AQ
TV41	AR
TV42	AS
TV43	AT

## Update ULXD Firmware

Often, the first step to troubleshooting an issue with ULXD transmitters or receivers is to perform a firmware update.

Find the current firmware version in the Device Utilities menu on the receiver.

- Receiver firmware version: Device Utilities > Version
- Transmitter firmware version: Device Utilities > Tx FW Update

To check for and install available updates, use [Shure Update Utility](#).

**Note:** If your receiver firmware is older than 2.0.28, refer to [ULX-D Firmware Update and Issues](#) for specific instructions.

For more detailed network setup instructions and information about firmware, refer to the [Shure Update Utility user guide](#).

## Firmware Versions

When you update receiver firmware, update your transmitters to the same firmware version to ensure consistent operation.

The firmware of all ULX-D devices has the form of MAJOR.MINOR.PATCH (e.g., 1.2.14). At a minimum, all ULX-D devices on the network (including transmitters), must have the same MAJOR and MINOR firmware version numbers (e.g., 1.2.x).

## Update the Receiver

First, use Shure Update Utility to send both receiver and transmitter firmware updates to the receiver.

**CAUTION!** Ensure that receiver power and network connections are maintained during a firmware update. Do not turn off the receiver until the update is complete.

**IMPORTANT!** Receivers running firmware prior to 1.4.8 must be updated to 1.4.8 before updating to newer versions. Receivers running firmware between 1.4.8 and 2.0.28 must be updated to 2.0.28 before updating to newer versions. See the [ULX-D Firmware Update and Issues FAQ](#) for more information on this update procedure.


1. Open Shure Update Utility.
2. Click Check Now or [#] updates available to view new versions available for download.
3. Select the updates and click Download.
4. Connect the receiver and computer to the same network.
5. Select a firmware package from the Version to install dropdown menu. Since multiple transmitter types are compatible with ULX-D receivers, firmware packages are named with keys to distinguish which transmitters they support.
  - Keys for firmware that supports ULXD1 and ULXD2 transmitters: ULX-DTx, ULX-D1GTX, ULX-D1smTx
  - Keys for firmware that supports ULXD8 and ULXD8 transmitters: ULX-DBGTx, ULX-DBG1GTX, ULX-DBGTxsm
6. From the Update Devices tab, send the latest firmware to the receiver.

For more information on the Shure Update Utility, refer to the [Shure Update Utility user guide](#).

## Update the Transmitter

1. Place the transmitter on a microphone or music stand, and roughly align the stand so that the transmitter's IR window can be aligned with the receiver. Shure does not recommend holding the transmitter during the update.
2. To upload the firmware to the transmitter, go to DEVICE UTILITIES > TX FW UPDATE on the receiver.
3. Align the IR ports.
4. Press ENTER on the receiver to begin the download to the transmitter. IR ports must be aligned for the entire download, which can take 50 seconds or longer.

## Batteries



The transmitter runs on two AA batteries or a Shure SB900 series rechargeable battery. Use the included AA battery adapter when using batteries other than the Shure rechargeable battery.

Bodypack: Remove the adapter when using the Shure rechargeable battery

Handheld: Rotate and store the adapter in battery door when using Shure rechargeable battery




## Battery Runtime Charts

A 5-segment icon on the receiver and transmitter menu screens indicates battery charge.

For accurate battery runtime monitoring, set the transmitter to the appropriate battery type: **UTILITY > BATTERY > SET .AA .TYPE.**

The tables display the approximate hours and minutes remaining (h:mm).

### Alkaline

<b>Battery Indicator</b>	<b>UHF/VHF</b>		<b>ISM/1.x</b>	
	<b>1/10 mW</b>	<b>20 mW</b>	<b>1/10mW</b>	<b>20mW</b>
	9:00 to 6:30	5:45 to 4:15	7:30 to 5:30	5:30 to 4:00
	6:30 to 4:00	4:15 to 3:00	5:30 to 3:30	4:00 to 2:45
	4:00 to 1:45	3:00 to 1:30	3:30 to 1:45	2:45 to 1:30
	1:45 to 0:45	1:30 to 0:30	1:45 to 0:45	1:30 to 0:30
	<0:45	<0:30	<0:45	<0:30
	Replace	Replace	Replace	Replace

## Shure SB900 Series Rechargeable Battery

When using a Shure rechargeable battery, the receiver and transmitter home screens display the number of hours and minutes remaining.

Detailed information for the rechargeable battery is displayed in the receiver BATTERY INFO menu and the transmitter menu: **UTILITY > BATTERY > BATT . STATS**

**HEALTH:** Displays battery health as a percentage of the charge capacity of a new battery.

**CHARGE:** Percentage of a full charge

**CYCLES:** Number of times the battery has been charged

**TEMP:** Battery temperature in Celsius and Fahrenheit

**Note:** For additional rechargeable battery information, visit [www.shure.com](http://www.shure.com).

<b>HEALTH:</b>	<b>90%</b>
<b>CHARGE:</b>	<b>80%</b>
<b>CYCLES:</b>	<b>100</b>
<b>TEMP:</b>	<b>10°C / 50°F</b>

# Important Tips for Care and Storage of Shure Rechargeable Batteries


Proper care and storage of Shure batteries results in reliable performance and ensures a long lifetime.

- Always store batteries and transmitters at room temperature
- Ideally, batteries should be charged to approximately 40% of capacity for long-term storage
- During storage, check batteries every 6 months and recharge to 40% of capacity as needed

## Installing the Battery Contact Cover

Install the included battery contact cover (65A15947) on the handheld transmitter to prevent light reflection in broadcast and performance situations.

1. Align the cover as shown.
2. Slide the cover over the battery contacts until it is flush with the transmitter body.



**Note:** Slide the cover off before inserting the transmitter in the battery charger.

## Setting Receiver Gain

The receiver gain control sets the audio signal level for the entire receiver and transmitter system. Changes to the gain settings occur in realtime allowing for adjustments during live performances. When adjusting the gain, monitor the audio meter levels to prevent signal overloads.

### Receiver Gain Controls

The gain can be adjusted by using the gain  $\blacktriangle$   $\blacktriangledown$  buttons or by entering the AUDIO menu and using the control wheel.

**Tip:** To quickly adjust the gain, press and hold a gain button to enable accelerated scrolling.

## Reading the Audio Meter



The audio meter displays yellow, green, and red LEDs to indicate the audio signal level. Audio peaks illuminate the LEDs for 2 seconds, while the RMS signal is displayed in realtime.

When setting up the receiver, adjust the gain so that the average signal LED levels are solid green and occasionally yellow, with only the highest peaks causing the red LED to illuminate.

**Tip:** If a vocalist is overloading a bodypack transmitter, try lowering the receiver gain. If additional attenuation is needed, use the transmitter menu to set the INPUT PAD to -12dB.

**Note:** Illumination of the red OL (overload) LED indicates the internal limiter is engaged to prevent digital clipping.

## Muting a Receiver Channel Audio Output

The audio output of each receiver channel can be independently muted to prevent audio from passing. Mute status is indicated by Rx MUTED message appearing on the receiver display in place of the gain value.

**Note:** Receiver gain is disabled for muted channels to prevent unexpected changes in audio levels.

To set a receiver channel output to mute:

1. AUDIO > MUTE
2. Use the control wheel to select ON or OFF.
3. Press ENTER to save.

To unmute the receiver output:

Simultaneously press the ▲ ▼ buttons or select OFF from the MUTE menu option.

**Tip:** Audio mute can be enabled remotely from Wireless Workbench or from an external controller.

**Important!** A power cycle will reset the receiver and unmute the audio output.

## Transmitter Input Clip

The following warning displays on the receiver LCD panel when the transmitter input is clipped:







To correct, select INPUT PAD from the main menu and attenuate the input signal by 12 dB. If the warning persists, reduce the level of input signal.

# Audio Summing

Audio summing allows the dual and quad receivers to function as a 2 or 4 channel mixer, respectively. Summed audio is available on all outputs (Dante and XLR). For example, when 1 + 2 is selected (see diagram), the outputs of channels 1 and 2 supply the summed audio of the two channels.

## Choosing an Audio Summing Mode

The following Audio Summing mode options are available:



To select an Audio Summing mode:

1. Menu: DEVICE UTILITIES > AUDIO SUMMING
2. Use the control wheel to select an option, and then press Enter.

**Note:** When set to OFF, Audio Summing is disabled.

## Adjusting Gain for Summed Outputs

Use the gain controls for each channel to create the overall mix balance. The front panel LEDs indicate the audio level for each channel. If an overload occurs, the red LEDs will illuminate indicating that the internal limiter is active and the display will show an overload message. To correct, adjust the overall gain balance.

## Receiver Output Level

The following table describes the typical total system gain from the audio input to the receiver outputs:

### Receiver Output Gain

Output Jack	System Gain (gain control = 0dB)
XLR (line setting)	+24 dB
XLR (mic setting)	-6 dB*

\*This setting matches a typical wired SM58 audio signal level.

## RF

## Transmitter RF Power

Reference the following table for setting RF Power:

RF Power Setting	System Range	Application
1 mW	33 m (100 ft.)	For increased channel reuse at close distances
10 mW	100 m (330 ft.)	Typical setups
20 mW	>100 m (330 ft.)	For hostile RF environments or long-distance applications

**Note:** Using the 20 mW setting decreases the transmitter battery runtime and reduces the number of compatible systems.

## Interference Detection



Interference Detection monitors the RF environment for potential sources of interference which can cause audio dropouts.

When interference is identified, the RF LEDs illuminate red and the following warning displays on the receiver LCD panel.

If the warning display persists or the audio drops out repeatedly, perform a Scan and Sync at the first opportunity to find a clear frequency.

## High Density Mode

High Density mode creates additional bandwidth for more channels in crowded RF environments. Frequency efficiency is optimized by running at 1 mW RF transmit power and narrowing the modulation bandwidth, allowing for the channel spacing to be reduced from 350 kHz to 125 kHz. Transmitters can be positioned on adjacent channels with unsubstantial intermodulation distortion (IMD).

High Density mode is ideal for applications where many channels are needed in a confined area, transmission distances are short, and the number of available frequencies is limited. Up to 30 meters of range is available in High Density mode.

### Setting the Receiver to High Density Mode

To set the receiver to High Density mode:

DEVICE UTILITIES > ADVANCED RF > HIGH DENSITY

Use the control wheel to set HIGH DENSITY to ON.

When prompted, sync the transmitter and receiver to enable HIGH DENSITY mode.

**Note:** When the receiver is in HIGH DENSITY mode, the following indicators are shown on the receiver display:

- The HD icon will appear on the receiver display
- The receiver band name will be shown with an "HD" added. (example: The G50 band will appear as G50HD)
- The transmitter group and channel are assigned letters instead of numbers (example: G:AA CH:AA)

### Best Practices for High Density Mode

- When band planning, position ULX-D High Density channels in a range of frequencies separated from other devices.
- Use a separate RF zone for ULX-D High Density channels to prevent intermodulation distortion from other devices.
- During High Density channel scanning, turn on all other transmitters and move them to their intended position.
- Perform a walk test to verify transmitter range
- If using custom groups, the groups loaded into the receiver must be compatible with High Density mode

## Frequency Diversity

Frequency diversity is an advanced ULX-D receiver feature that safeguards against loss of audio signal caused by RF interference or by power loss in a transmitter.

In frequency diversity mode, the signals from two transmitters from a common audio source are routed to the outputs of 2 receiver channels. In the event of interference or power loss, the audio from the good channel is switched to both outputs to preserve the audio signal. Switching between channels is seamless and inaudible.

When the receiver senses that the signal quality has improved, audio routing is restored without interrupting the audio signal.

**Note:** In Wireless Workbench, you can selectively lock the diversity audio source to a specific transmitter. See "Lock or Unlock a Frequency Diversity Channel" in the [Wireless Workbench help system](#) for more on this.

### Best Practices for Frequency Diversity

- Use the same microphone type and model for each transmitter
- Place microphones within close proximity to the source
- Use the gain controls to match the output levels for each receiver channel
- If audio summing is active, use a Y-cable (Shure AXT652) to connect the bodypacks to a single audio source to prevent comb filtering

## Choosing Diversity Output Routing

The following receiver channel routing output options are available:

- 1 + 2
- 3 + 4 (quad only)
- 1 + 2 / 3 + 4 (quad only)

To enable frequency diversity and select a routing option:

DEVICE UTILITIES > FREQ DIVERSITY

Use the control wheel to choose a routing option, and then press ENTER.

**Note:** Choose OFF to disable frequency diversity.

## Frequency Diversity and Encryption

Enabling encryption while in frequency diversity mode provides an additional layer of protection by only passing audio from the most recently synced encrypted transmitter for each receiver channel.

## Setting Regional TV Format

To ensure accurate display of TV channel information, set the TV FORMAT to match the TV channel bandwidth in the region where the receiver is operating. TV bandwidth varies globally, so check local regulations to determine the regional TV bandwidth.

The following TV FORMAT options are available:

- 6 MHz
- 7 MHz
- 8 MHz
- 6 MHz JAPAN
- NO TV (use to turn off TV channel display or in regions where TV channels are not applicable)

To set the TV FORMAT:

1. Menu: DEVICE UTILITIES > ADVANCED RF > TV FORMAT
2. Use the control wheel to select a TV FORMAT option.
3. Press ENTER to save.

## Custom Groups

Use this feature to create and export up to 6 groups of manually selected frequencies to networked receivers prior to a group scan to simplify system set up.

**Tip:** Use Wireless Workbench or Wireless Frequency Finder to select the best compatible frequencies. See [www.shure.com](http://www.shure.com) for more information.

To create a custom group: DEVICE UTILITIES > ADVANCED RF > CUSTOM GROUPS > SETUP

Use the control wheel to choose group, channel and frequency values. Press ENTER to save.

Prior to performing a group scan, export a custom group to networked receivers:

1. Go to DEVICE UTILITIES > ADVANCED RF > CUSTOM GROUPS > EXPORT
2. Press the flashing ENTER button to export all custom groups to all receivers on the network.

**Note:** Use the CLEAR ALL option to remove all custom group settings.

# Audio Signal Encryption

When encryption is enabled, the receiver generates a unique encryption key which is shared with the transmitter during an IR sync. Transmitters and receivers that share an encryption key form a protected audio path, preventing unauthorized access from other receivers.

**Note:** For some units, encryption is always on and cannot be configured.

## Encrypting a Single Transmitter to a Single Receiver

1. From the receiver menu: DEVICE UTILITIES > ENCRYPTION > ON (Auto)
2. Press ENTER.
3. Perform an IR Sync to share the encryption key with the selected transmitter.

## Encrypting Multiple Transmitters to a Single Receiver

Multiple transmitters can share the same encryption key, allowing them access to a single receiver. Use this method if you have multiple instruments or wish to use a combination of handheld and bodypack transmitters.

1. From the receiver menu: DEVICE UTILITIES > ENCRYPTION > ON (Manual) > KEEP KEYS.
2. Press ENTER.
3. Perform an IR Sync to share the encryption key with the first transmitter.
4. Turn off the transmitter and perform an IR Sync to share the key additional transmitters.

**Caution!** Make sure only one transmitter is turned on during an IR sync or a performance to avoid causing cross interference between transmitters.

## Regenerating Encryption Keys

Periodically regenerating the encryption key maintains security for transmitters and receivers that are paired for extended periods.

1. From the receiver menu: DEVICE UTILITIES > ENCRYPTION > ON (Manual) > REGENERATE KEYS.
2. Press ENTER.
3. Perform an IR Sync to share the encryption key with the first transmitter.
4. Turn off the transmitter and perform an IR Sync to share the key additional transmitters.

**Caution!** Make sure only one transmitter is turned on during an IR sync or a performance to avoid causing cross interference between transmitters.

## Removing Encryption

**Note:** For some units, encryption is always on and cannot be configured.

1. From the receiver menu: DEVICE UTILITIES ENCRYPTION OFF
2. Press ENTER.
3. IR Sync the transmitter and receiver to clear the encryption key.

**Note:** If multiple transmitters are encrypted to a single receiver, each transmitter must be IR synced to clear the encryption key.

## RF Cascade Ports

The receiver has 2 RF cascade ports on the rear panel to share the signal from the antennas with 1 additional receiver.

Use a shielded coaxial cable to connect the RF cascade ports from the first receiver to the antenna inputs of the second receiver.

**Important!** The frequency band must be the same for both receivers.

## Antenna Bias

Antenna ports A and B provide a DC bias to power active antennas. Set the DC power to off when using passive (non-powered) antennas.

To turn bias off: DEVICE UTILITIES > ADVANCED RF > ANTENNA BIAS > OFF

## Networking ULX-D Receivers

ULX-D Dual and Quad receivers feature a Dante dual-port network interface. Dante technology provides an integrated solution to distribute digital audio, manage control signals, and carry Shure Control (WWB and AMX/Crestron) signals. Dante uses standard IP over Ethernet and safely coexists on the same network as IT and control data. Selectable Dante networking modes route port signals for flexible network set up.

## Network Control Software

You can remotely manage and monitor your ULX-D receivers using Wireless Workbench and monitor digital audio routing using the Dante Controller. Signals for AMX and Crestron controllers are carried on the same network as Shure Control.

### Shure Control

Wireless Workbench (WWB) software provides comprehensive control for wireless audio systems. Wireless Workbench enables live remote adjustments to networked receivers for real-time changes to gain, frequency, RF power, and control locks. A familiar channel strip interface displays audio meters, transmitter parameters, frequency settings and network status.

Wireless Workbench is available for Windows or Mac and can be downloaded at: [www.shure.com/wwb](http://www.shure.com/wwb)

### Dante

The Dante controller is a free software program created by Audinate™ to configure and manage a network of Dante enabled devices. Use the controller to create audio routes between networked components and to monitor the status of online devices.

Visit [www.audinate.com](http://www.audinate.com) for download and installation instructions.

### Dante Controller and Lock Settings

Version 2.4.X introduces support for Dante Device Lock for ULXD4D and ULXD4Q. Dante Device Lock is a feature of Dante Controller that allows you to lock and unlock supported Dante devices using a 4-digit PIN (Personal Identification Number). When a device has a Dante lock turned on, Dante audio will continue to flow according to existing subscriptions, but its subscriptions and settings can't be controlled or configured.

If you forget your Dante Device Lock PIN, see the Device Lock section of the Dante Controller User Guide for instructions on how to proceed.

### Dante Domain Manager

Version 2.4.X introduces support for Dante Domain Manager (DDM) for ULXD4D and ULXD4Q. DDM is network management software that enables user authentication, role based security, and audit capabilities for Dante networks and Dante-enabled products.

Considerations for Shure devices controlled by DDM:

- When you add Shure devices to a Dante domain, leave the local controller access setting in Read Write. Otherwise, access to Dante settings, device factory reset, and device firmware updates will be disabled.

- When a device is managed by a Dante Domain and the Dante Domain is disconnected, access to Dante settings, device factory reset and device firmware updates will be disabled. When a device reconnects to the Dante Domain, it follows the policy set for it in the Dante Domain.

See the Dante Domain Manager User Guide for more information.


## IP Address Configuration

An IP address must be assigned to each device in the network to ensure communication and control between components. Valid IP addresses can be assigned automatically using a DHCP server or manually from a list of valid IP addresses. If using Dante audio, a separate Dante IP address must also be assigned to the receiver.

### Automatic IP Addressing

- If using a DHCP capable Ethernet switch, set the DHCP switch to ON.
- Set the IP Mode to Automatic for all receivers: DEVICE UTILITIES > NETWORK > SHURE CONTROL > NETWORK
- Use the control wheel to set the mode to Automatic, press ENTER to save.

**Note:** Use only one DHCP server per network.



### Manual IP Addressing

- Connect the receivers to an Ethernet switch.
- Set the IP Mode to Manual for all devices: DEVICE UTILITIES > NETWORK > SHURE CONTROL > NETWORK
- Use the control wheel to set the mode to Manual.
- Set valid IP addresses and subnet values for all devices, press ENTER to save.

### Dante IP Addressing

IP addresses for a Dante network can be assigned automatically using a DHCP server or manually from a list of valid IP addresses.

To select the Dante IP addressing mode (Automatic or Manual): DEVICE UTILITIES > NETWORK > DANTE > AUDIO & CNTRL

Use the control wheel to select the mode, and then press ENTER to save.

## Networking Acronyms

**DHCP:** Dynamic Host Configuration Protocol

**LAN:** Local Area Network

**MCU:** Micro Controller Unit

**RJ45:** Ethernet connection


**RX:** Receiver

**TX:** Transmitter**WWB:** Wireless Workbench software**VLAN:** Virtual Local Area Network**MAC:** Machine Access Code

## Overview of Dante Network Modes

The Dante network interface has two ports (Primary and Secondary) to provide flexible routing and configuration options for network signals.

Three selectable Dante network modes are available to control signal routing from the receiver ports to the Dante network.



Network Mode	Port Function and Signals		Application
	Secondary	Primary	
<b>SWITCHED</b>	Shure Control Dante Audio and Control	Shure Control Dante Audio and Control	For single network installations of star or daisy-chained networks.
<b>REDUNDANT AUDIO</b>	Dante Redundant Audio	Shure Control Dante Audio and Control	Primary and Secondary ports are configured as 2 separate networks. The Secondary port carries a backup copy of the Primary digital audio signal.
<b>SPLIT</b>	Dante Audio and Control	Shure Control	Primary and Secondary ports are configured as 2 separate networks to provide isolation between control signals and audio signals.

## Setting the Dante Networking Mode

Select a Dante mode to configure network signal routing on the Primary and Secondary ports. Set all receivers on the network to the same mode.

**Note:** Remove network connections from the receiver before changing the mode.

1. From the receiver menu: DEVICE UTILITIES > NETWORK > CONFIGURATION
2. Use the control wheel to select a mode (SWITCHED, REDUNDANT AUDIO, SPLIT)
3. Press ENTER to save.
4. Cycle receiver power to enable the mode change.

# Network Connection and Configuration Examples


**Note:** Use shielded Cat5e cable for network connections to ensure reliable performance.

## Switched Mode

Switched mode is typically used for single network installations of star or daisy-chained networks. Switched mode is recommended for installations that don't require Dante audio.

Network characteristics:

- Dante Audio and Shure Control are present on both the Primary and Secondary ports
- The Dante IP address and the Shure Control IP address must be on the same subnet. The computer running Wireless Workbench must also be on this subnet.



Network Example (Dante Audio + Wireless Workbench)

① Computer

Connect the computer running the Dante controller and Wireless Workbench to the Primary port.

## ② DHCP Server

Can be configured with or without a DHCP server. Do not route audio through the server.

## ③ Gigabit Ethernet Switch


- Do not connect both network ports to the same Ethernet switch
- Use a star network topology to minimize audio latency

## ④ Receiver Connection

Connect receivers to the Primary port

## ⑤ Dante Receiver

Connect Dante receivers (mixers, recorders, amplifiers) to the Primary port.



## Network Example (Wireless Workbench Only)

### ① Computer


Connect the computer running Wireless Workbench to the Primary port.

### ② DHCP Server

Can be configured with or without a DHCP server.

### ③ Receiver Connection

Connect receivers to the Primary port



## Redundant Audio Mode

Use redundant mode to carry a backup copy of the Dante audio on the Secondary network in case the audio on the primary network is interrupted.

Network characteristics:

- Dante Primary Audio and Shure Control are present on the Primary port
- Backup Dante audio is present on the Secondary port
- The Primary Dante IP address and the Shure Control IP address must be on the same subnet. The computer running Wireless Workbench must also be on this subnet.
- The Secondary Dante IP Address must be set to a different subnet

**Note:** Devices connected to the Redundant network must be compatible with Redundant audio.

## Network Example

### ① Computer

Connect the computer running the Dante controller and Wireless Workbench to the Primary port.

### ② DHCP Server

Can be configured with or without a DHCP server. Do not route audio through the server.

### ③ Gigabit Ethernet Switches

- Use dedicated switches for the Primary and Secondary networks

- Do not connect both network ports to the same Ethernet switch
- Use a star network topology to minimize audio latency


## ④ Receiver Connection

Connect Primary and Secondary ports to dedicated switches.

**Note:** The Secondary port only supports manual IP or automatic Link-Local configuration. The Link-Local Dante Secondary address subnet is preset to 172.31.x.x (255.255.0.0)

## ⑤ Dante Receiver

Connect Dante receivers (mixers, recorders, amplifiers) to the Primary or Secondary ports.



## Split Mode

Use Split Mode to isolate control signals from audio signals by placing them on two separate networks.

Network Characteristics:

- Shure Control is present on the Primary port
- Dante Audio is present on the Secondary port
- The IP addresses for Dante and Shure Control must be on different subnets

# Network Example

## ① Computer (Dante Controller)

Connect the computer running the Dante controller to the Secondary port.

## ② DHCP Server (Secondary Network)

Can be configured with or without a DHCP server. Do not route audio through the server.

## ③ Gigabit Ethernet Switch (Secondary Network)

- Use dedicated switches for the Primary and Secondary networks
- Do not connect both network ports to the same Ethernet switch
- Use a star network topology to minimize audio latency

## ④ Receiver Connections (Dante Audio)

Connect the Secondary ports to the Secondary network switch.

## ⑤ Computer (Shure Control)

Connect the computer running the Shure Control to the Primary port.

## ⑥ DHCP Server (Primary Network)

Can be configured with or without a DHCP server. Do not route audio through the server.

## ⑦ Gigabit Ethernet Switch (Primary Network)


- Use dedicated switches for the Primary and Secondary networks
- Do not connect both network ports to the same Ethernet switch
- Use a star network topology to minimize audio latency

## ⑧ Receiver Connections (Shure Control)

Connect the Primary ports to the Primary network switch.

## ⑨ Dante Receiver

Connect Dante receivers (mixers, recorders, amplifiers) to the Primary port.



## Assigning Network Device IDs for Shure Control and Dante Control

When using the receiver in a network with Shure Control (Wireless Workbench) and a Dante Controller, two Device IDs are required: one for Shure Control and one for Dante Control. Device IDs are used to identify devices on the network and for creating Dante digital audio routes.

### Best Practices

Using the following best practices will help to organize network setup and ease troubleshooting.

- For consistency, convenience, and easy troubleshooting, use the same device ID for both Wireless Workbench (Shure Control) and for the Dante network.
- The Dante network requires unique Dante device IDs to prevent a loss of audio signal routing. Any duplicate IDs on the network will be tagged with a number such as -1, -2, -3, etc.... and must be changed to a unique value.
- Wireless Workbench (Shure Control) does not require unique device IDs and duplicates do not affect the Dante network; however, a best practice is to use unique device IDs.

### Setting the Shure Control Device ID

1. Launch Wireless Workbench.
2. In the inventory, double-click the device ID to edit it.

**Tip:** Click the device icon next to the channel name flash the front panel and identify the receiver.

You can also update the Shure control device ID from the receiver front panel:

1. From the receiver menu: DEVICE UTILITIES > NETWORK > SHURE CONTROL > Dev. ID
2. Use the control wheel to edit the ID.
3. Press ENTER to save.

## Creating a Dante Device ID

There are two ways to create a Dante ID:

1. Enter the ID using the receiver menu.
2. Enter the ID using a keyboard from the Dante controller.

If entering IDs from the receiver menu, additional ID modes are available for quickly adding sequential numbering to multiple receivers or adding a prefixes for network discovery by Dante enabled Yamaha mixing consoles.

**Note:** Changing the Dante ID will cause a loss of audio signal. After an ID has been changed, use the Dante controller to restore audio route subscriptions using the new ID.

Setting the Device ID from the receiver menu:

1. DEVICE UTILITIES > NETWORK > DANTE > Dev. ID
2. Use the control wheel to select an ID MODE:
  - Off: Manually enter an ID by using the control wheel. Press ENTER to save.
  - Sequential: Adds a 3-digit numerical prefix to the receiver model name to create the device ID. (ex: 001-Shure-ULXD). Use the control wheel to increment the prefix value. Press ENTER to save.
  - Yamaha: Adds a prefix starting with "Y" followed by 3-digits to the receiver model name to create a device ID that allows Dante enabled Yamaha mixing consoles to discover ULX-D receivers on a Dante network. (ex: Y001-Shure-ULXD). Use the control wheel to increment the prefix numerical value. Press ENTER to save.

Entering the Device ID from the Dante controller:

1. Open the Device View and select the receiver from the pulldown menu.
2. Click on the Device Config tab.
3. Enter the ID in the Rename Device box and press ENTER.

## Viewing Dante Device IDs in the Dante Controller

Dante device IDs are displayed in the Network View window in the Dante Controller.

1. Launch the Dante controller and open the Network View window.
2. Verify that the Dante device IDs match the IDs entered in the receiver.

## Identify Device Feature

The Dante controller's Identify Device feature flashes the front panel LEDs of a selected receiver to provide identification when multiple receivers are in use.

Open the Device View in the Dante controller and click on the identify icon (eye). The front panel LEDs of the selected receiver will respond by flashing.

## Route Audio with Dante Controller

In Dante Controller, devices are categorized as "transmitters" and "receivers"

In order for audio to flow in the network, audio routes (subscriptions) must be configured between transmitters and receivers. To learn about creating subscriptions between devices, see the [Dante Controller](#) user guide.

**Note:** ULX-D receivers will appear in Dante Controller as a transmitter. Devices that have both inputs and outputs commonly appear as both transmitters and receivers.

## Network Troubleshooting

- Use only one DHCP server per network
- All devices must share the same subnet mask
- All receivers must have the same level of firmware revision installed
- Look for the illuminated network icon on the front panel of each device:

If the icon is not illuminated, check the cable connection and the LEDs on the network jack.

If the LEDs are not on and the cable is plugged in, replace the cable and recheck the LEDs and network icon.

For more information, see the [Wireless Workbench help system](#).

## Restoring Dante Factory Settings

The receiver and the Dante network card can be reset to restore factory Dante settings. Performing a reset is helpful for clearing existing data before setting up a system.



**Caution!** Performing a reset on either the Dante network card or on the ULX-D receiver will interrupt the Dante audio.

**Tip:** Prior to performing a factory reset, note the current Dante network mode and IP settings. After a reset, the Dante network mode reverts to SWITCHED, and the IP address mode revert to AUTO.

### Restoring Receiver and Dante Card Factory Settings

Performing a reset from the receiver restores the factory settings and configures the Shure Control and Dante IP address mode to AUTO.

1. From the receiver menu: DEVICE UTILITIES > SYSTEM RESET > RESTORE DEFAULT SETTINGS
2. Press ENTER to complete the reset.



### Restoring the Dante Network Card Factory Settings

The Factory Reset option within the Dante controller restores the Dante card to the factory settings and configures the Dante IP address mode to AUTO.

1. From the Dante controller, select a receiver and open the Network Config tab.
2. Click on Factory Reset.
3. Allow the Dante controller to refresh before making any additional changes.



## System Reset

System Reset clears the current receiver settings and restores the factory default settings.

To restore factory default settings:

1. Go to DEVICE UTILITIES > SYSTEM RESET > RESTORE.
2. Scroll to the DEFAULT SETTINGS option and press ENTER.
3. Press the flashing ENTER button to return the receiver to the default settings.

## Connecting to an External Control System

The ULX-D receiver is compatible with external control systems such as AMX or Crestron via the Ethernet, using the same cables used to carry Shure Control (Wireless Workbench). Use only one controller per system to avoid messaging conflicts.

- Connection: Ethernet (TCP/IP; ULX-D receiver is the client)
- Port: 2202

For a comprehensive list of ULX-D command strings, see [the Shure ULX-D command string FAQ page](#).

## Setting the Gateway to Allow Cross Subnet Routing

ULX-D receivers include gateway addressing to support cross-subnet routing. The gateway setting allows a single controller to manage devices assigned to different subnets such as multiple rooms or multiple buildings.

**Note:** A gateway address is an advanced network setting. In most network configurations, the setting does not need to be changed.

To set the receiver gateway:

1. From the receiver menu: DEVICE UTILITIES > NETWORK > SHURE CONTROL > NETWORK
2. Press and turn the control wheel to set the Mode to Manual.
3. Press the control wheel to navigate to the first digit of the GW (gateway) setting.
4. Turn the control wheel to change a value, press the control wheel to advance to the next octet.
5. When finished, press ENTER to save.

**Note:** When setting the gateway address, the IP address and subnet must be set to valid addresses.

## Shure Wireless Coordination and Management Tools

Use Wireless Workbench and Wireless Workbench mobile to help manage, organize, and coordinate frequencies for your wireless systems.

## Wireless Workbench

Shure Wireless Workbench is a free software application designed to help you manage the RF spectrum and control wireless devices.

- Download Wireless Workbench: [shu.re/wwb](http://shu.re/wwb)
- Get help with Wireless Workbench: [shu.re/wwb-help](http://shu.re/wwb-help)

## Wireless Workbench Mobile

Wireless Workbench Mobile brings wireless monitoring and control to your iOS or Android mobile device in a streamlined format built for field use. Use alongside Wireless Workbench or as a stand-alone application for less complex coordination needs.

- Download Wireless Workbench Mobile: <https://www.shure.com/en-US/docs/guide/wireless-workbench-mobile>
- Get help with Wireless Workbench Mobile: [https://www.shure.com/en-US/products/software/wireless\\_workbench\\_mobile](https://www.shure.com/en-US/products/software/wireless_workbench_mobile)

## Troubleshooting

Issue	Solution
<b>No Sound</b>	See below: Power, Cables, Radio Frequency, or Encryption Mismatch
<b>Faint sound or distortion</b>	Adjust the system gain on the front of the receiver. Ensure the output level (XLR output only) on the back of the receiver corresponds to the input of the mixing console, amplifier, or DSP.
<b>Lack of range, unwanted noise bursts, or dropouts</b>	See below: RF
<b>Cannot turn transmitter off or change frequency settings, or can't program receiver</b>	The transmitter and the receiver can be locked to prevent accidental or unauthorized changes. A locked feature or button will produce the Locked screen on the LCD panel.
<b>Encryption Mismatch message</b>	Re-sync all receivers and transmitters after enabling or disabling encryption
<b>Firmware Mismatch message</b>	Paired transmitters and receivers must have the same firmware version installed to ensure consistent operation. Refer to <a href="#">Update ULX-D Firmware</a> for more information.
<b>Tx Type Mismatch message</b>	Refer to the <a href="#">Transmitter Type Mismatch FAQ</a> for steps to resolve

Issue	Solution
<b>Antenna Fault message</b>	<p>Indicates a short circuit condition at an antenna port.</p> <p>Check antennas and cables for damage Ensure that antenna ports are not overloaded Check antenna bias voltage setting. Turn off voltage if using passive antennas.</p>
<b>Tx Battery Hot message</b>	<p>If the transmitter battery does not cool off, the transmitter will shut down. Let the device cool down and then consider swapping the transmitter battery to continue operation.</p> <p>Identify any possible external heat sources to the transmitter and operate the transmitter away from those external heat sources.</p> <p>All batteries should be stored and operated away from external heat sources in reasonable temperature conditions for best performance.</p>

## Power

Make sure that the receiver and transmitter are receiving sufficient voltage. Check the battery indicators and replace the transmitter batteries if necessary.

## Cables

Check that all cables and connectors are working correctly.

## Encryption Mismatch

Enable or disable encryption and re-sync all receivers and transmitters. Refer to [Audio Signal Encryption](#) for instructions.

## Radio Frequency (RF)

### RF LEDs

If neither blue RF Diversity LED is illuminated, then the receiver is not detecting the presence of a transmitter.

The amber RF Signal Strength LEDs indicate the amount of RF power being received. This signal could be from the transmitter, **or it could be from an interfering source, such as a television broadcast**. If more than one or two of the amber RF LEDs are still illuminated while the transmitter is off, then that channel has too much interference, and you should try a different channel.

The red RF LED indicates RF overload. This will usually not cause a problem unless you are using more than one system at the same time, in which case, it can cause interference **in the other system**.

## Compatibility

- Perform a Scan and Sync to ensure the transmitter and receiver are set to the same group and channel.
- Look at the label on the transmitter and receiver to make sure they are in the same band (G50, J50, L50, etc...).

## Reducing Interference

- Perform a group or channel scan to find the best open frequency. Perform a sync to transfer the setting to the transmitter.
- For multiple systems, check that all systems are set to channels in the same group (systems in different bands do not need to be set to the same group).
- Maintain a line of sight between transmitter and receiver antennas.
- Move receiver antennas away from metal objects or other sources of RF interference (such as CD players, computers, digital effects, network switches, network cables and Personal Stereo Monitor (PSM) wireless systems).
- Eliminate RF overload (see below).

## Increasing Range

If the transmitter is more than 6 to 60 m (20 to 200 ft) from the receiver antenna, you may be able to increase range by doing one of the following:

- Reduce interference (see above).
- Increase transmitter RF power level.
- Use Normal mode instead of High Density mode.
- Use an active directional antenna, antenna distribution system, or other antenna accessory to increase RF range.

## Eliminating RF Overload

If you see the red RF LED on a receiver, try the following:

- Reduce the transmitter RF power level
- Move the transmitter further away from the receiver—at least 6 m (20 ft)
- If you are using active antennas, reduce antenna or amplifier gain.
- Use omnidirectional antennas

## Contact Customer Support

Didn't find what you need? [Contact our customer support](#) to get help.

## Included Components

### All Systems

Component	Part number
Receiver	ULXD4D, ULXD4Q
1/2-Wave Receiver Antennas (2)	frequency band dependent

Component	Part number
Hardware Kit (Rack mounting Screws)	90XN1371
22 in. BNC-BNC Coaxial Cable(2)	95K2035
Bulkhead Adapter (2)	95A8994
Ethernet Cable 3 ft.	95B15103

## Handheld Systems

Component	Part number
Handheld transmitter	ULXD2
Cartridge	see options below
Microphone Clip	95T9279
Zipper Bag	95B2313
AA alkaline batteries (2)	80B8201
Battery Contact Cover	65A15947

Choice of 1 of the following:

- SM58 (RPW112)
- SM86 (RPW114)
- SM87A (RPW116)
- Beta 58A (RPW118)
- Beta 87A (RPW120)
- Beta 87C (RPW122)
- KSM8 Nickel (RPW170)
- KSM8 Black (RPW174)
- KSM9 (RPW184)
- KSM9HS (RPW186)
- KSM11 Black (RPW194)
- NXN8/C Black (RPW200)
- NXN8/C Nickel (RPW202)
- NXN8/S Black (RPW204)
- NXN8/S Nickel (RPW206)

## Bodypack System

Component	Part number
Bodypack transmitter	ULXD1
1/4-Wave transmitter antennas	frequency band dependent
Zipper Bag	95A2313
AA batteries (2)	80B8201

Choice of 1 of the following:

- Cable, Instrument, 2.5 foot (.75 m), 4 Pin Mini Connector (TA4F) to 1/4-inch Connector. (WA302)
- Instrument Clip-on microphone (Beta 98H/C)
- Lavalier microphone (MX150, MX153, WL183, WL184, WL185)
- Headset microphone (WH30TQG)
- Cable, Instrument, 2-foot (0.7m), 4-pin Mini Connector (TA4F) with Right-Angle 1/4-inch Connector, used with Shure Wireless Bodypack Transmitters (WA304)
- Premium Guitar Cable TQG Latching Connector (WA306)
- Premium 1/4" Right-Angle (WA307)
- LEMO to 1/4" (WA308)
- LEMO to 1/4" Right-Angle (WA309)

## Antennas

Band	1/2-Wave Receiver Antennas	1/4-Wave Transmitter Antennas
<b>G50</b>	95AA9279	95G9043 (Yellow)
<b>G51</b>	95AA9279	95G9043 (Yellow)
<b>G52</b>	95AA9279	95G9043 (Yellow)
<b>H51</b>	95AL9279	95D9043 (Gray)
<b>H52</b>	95AL9279	95D9043 (Gray)
<b>J50</b>	95AK9279	95E9043 (Black)
<b>K51</b>	95AJ9279	95E9043 (Black)
<b>L50</b>	95AD9279	95E9043 (Black)
<b>L51</b>	95AD9279	95E9043 (Black)
<b>P51</b>	95AF9279	95F9043 (Blue)
<b>R51</b>	95M9279	95F9043 (Blue)
<b>AB</b>	95M9279	N/A
<b>Q51</b>	95M9279	N/A

## Optional Accessories

Accessory	Part number
<b>Shure Lithium-Ion Rechargeable Battery</b>	SB900C
<b>8-Bay Shure Battery Charger</b>	SBC800
<b>Dual Docking Charger, Power Supply Not Included</b>	SBC200
<b>Boundary Transmitter</b>	ULXD6

Accessory	Part number
ULXD Gooseneck Base Transmitter	ULXD8
4-bay networked docking station for gooseneck and boundary microphones	SBC450
8-bay networked docking station for gooseneck and boundary microphones	SBC850
Carrying Case	WA610
Black Bodypack Pouch	WA582B
Y-Cable for bodypack transmitters	AXT652
Antenna Distribution System	UA845SWB
Passive Antenna/Splitter Combiner Kit (recommended for 2 receivers)	UA221
In-Line Antenna Amplifier, 470-698MHz	UA830USTV
UHF Antenna Power Distribution Amplifier (recommended for 3 or more receivers)	UA844SWB
In-Line Power Supply	UABIAST
Front Mount Antenna Kit (Includes 2 Cables And 2 Bulk-head)	UA600
1/2 Wave Antenna Remote Mount Kit	UA505
Active Directional Antenna 470-900MHz	UA874WB
Passive Directional Antenna 470-952 MHz. Includes 10 foot BNC to BNC cable.	PA805SWB
2 ft. BNC-BNC Coaxial Cable	UA802
6 foot (1.8m) BNC to BNC Coaxial Cable for Remote Antenna Mounting for ULX Wireless System	UA806
25 ft. BNC-BNC Coaxial Cable	UA825
50 ft. BNC-BNC Coaxial Cable	UA850
100 ft. BNC-BNC Coaxial Cable	UA8100

# Specifications

## ULX-D System Specifications

### RF Carrier Frequency Range

470–932 MHz, varies by region (See Frequency Range and Output Power table)

### Working Range

100 m ( 330 ft)

Note: Actual range depends on RF signal absorption, reflection and interference.  
Note: Actual range depends on RF signal absorption, reflection and interference.

### RF Tuning Step Size

25 kHz, varies by region

### Image Rejection

>70 dB, typical

### RF Sensitivity

–98 dBm at  $10^{-5}$  BER

### Latency

<2.9 ms

### Audio Dynamic Range

*A-weighted, typical, System Gain @ +10*

<b>XLR Analog Output</b>	>120 dB
<b>Dante Digital Output</b>	130 dB

### Total Harmonic Distortion

*–12 dBFS input, System Gain @ +10*

<0.1%

### System Audio Polarity

Positive pressure on microphone diaphragm produces positive voltage on pin 2 (with respect to pin 3 of XLR output) and the tip of the 6.35 mm (1/4-inch) output.

### Operating Temperature Range

–18°C (0°F) to 50°C (122°F)

Note: Battery characteristics may limit this range.

### Storage Temperature Range

–29°C (-20°F) to 74°C (165°F)

Note: Battery characteristics may limit this range.

## ULXD4D & ULXD4Q

### ULXD4D

#### Weight

3.36 kg (7.4 lbs), without antennas

#### Power Requirement

100 to 240 V AC, 50-60 Hz, 0.26 A max.

### ULXD4Q

#### Weight

3.45 kg (7.6 lbs), without antennas

#### Power Requirement

100 to 240 V AC, 50-60 Hz, 0.32 A max.

### ULXD4D & ULXD4Q

#### Dimensions

44 x 482 x 274 mmH x W x D

#### Housing

steel; Extruded Aluminum

## Audio Output

#### Gain Adjustment Range

-18 to +42 dB in 1 dB steps (plus Mute setting)

#### Configuration

XLR	balanced (1=ground, 2=audio +, 3=audio -)
-----	-------------------------------------------

#### Impedance

100 Ω

#### Full Scale Output

LINE setting	+18 dBV
MIC setting	-12 dBV

#### Mic/Line Switch

30 dB pad

#### Phantom Power Protection

Yes

## Cascade Output

### Connector Type

BNC

Note: For connection of one additional receiver in the same band

### Configuration

Unbalanced, passive

### Impedance

50 Ω

### Insertion Loss

0 dB

## Networking

### Network Interface

Dual Port Ethernet 10/100 Mbps, 1Gbps, Dante Digital Audio

### Network Addressing Capability

DHCP or Manual IP address

### Maximum Cable Length

100 m (328 ft)

## RF Input

### Spurious Rejection

>80 dB, typical

### Connector Type

BNC

### Impedance

50 Ω

### Bias Voltage

12 to 13 V DC, 150 mA maximum, per antenna

switchable on-off

## ULXD1

### Mic Offset Range

0 to 21 dB (in 3 dB steps)

### Audio Frequency Response

20 – 20 kHz ( $\pm 1$  dB)

**Battery Type**

Shure SB900-series Rechargeable Li-Ion or LR6 AA batteries 1.5 V

**Battery Runtime**

@ 10 mW

Shure SB900C	>11 hours
alkaline	9 hours

See Battery Runtime Chart

**Dimensions**

86 mm x 66 mm x 23 mm (3.4 in. x 2.6 in. x 0.9 in.) H x W x D

**Weight**

142 g (5.0 oz.), without batteries

**Housing**

Cast aluminum

## Audio Input

**Connector**

4-Pin male mini connector (TA4M), See drawing for details

**Configuration**

Unbalanced

**Impedance**

1 MΩ, See drawing for details

**Maximum Input Level**

1 kHz at 1% THD

Pad Off	8.5 dBV ( 7.5 Vpp)
Pad On	20.5 dBV ( 30 Vpp)

**Preamplifier Equivalent Input Noise (EIN)**System Gain Setting  $\geq$  +20-120 dBV, A-weighted, typical

## RF Output

**Connector**

SMA

**Antenna Type**

1/4 wave

**Impedance**

50 Ω

**Occupied Bandwidth**

&lt;200 kHz

**Modulation Type**

Shure proprietary digital

**Power**

1 mW, 10 mW, 20 mW

See Frequency Range and Output Power table, varies by region

## ULXD2

### Mic Offset Range

0 to 21 dB (in 3 dB steps)

### Audio Frequency Response

Note: Dependent on microphone type

### Battery Type

Shure SB900-series Rechargeable Li-Ion or LR6 AA batteries 1.5 V

### Battery Runtime

@ 10 mW

<b>Shure SB900C</b>	>11 hours
<b>alkaline</b>	9 hours

See Battery Runtime Chart

### Dimensions

<b>VHF V50 and V51</b>	278 mm x 51 mm (10.9 in. x 2.0 in.) L x Dia.
<b>Other frequency bands</b>	256 mm x 51 mm (10.1 in. x 2.0 in.) L x Dia.

### Weight

<b>VHF V50 and V51</b>	348 g (12.3 oz.), without batteries
<b>Other frequency bands</b>	340 g (12.0 oz.), without batteries

### Housing

Machined aluminum

## Audio Input

### Configuration

Unbalanced

### Maximum Input Level

1 kHz at 1% THD 145 dB SPL (SM58), typical

Note: Dependent on microphone type

## RF Output

### Antenna Type

Integrated Single Band Helical

### Occupied Bandwidth

<200 kHz

### Modulation Type

Shure proprietary digital


### Power

1 mW, 10 mW, 20 mW


See Frequency Range and Output Power table, varies by region

## Tables and Diagrams

### TA4M Connector




### LEMO Connector



### XLR to 1/4 Output

Use the following wiring diagram to convert the XLR output to a 1/4 output.



\* No Connection

# Batteries

## ULXD Battery Life

MHz	hours		alkaline		
	SB900C	1/10 mW	20 mW	1/10 mW	20 mW
<b>470 to 810</b>	>11:30		>7:40	>8	>5:30
<b>902 to 928</b>	>10:10		>6:20	>7	>4
<b>174 to 216</b>	>11:30		>8:55	8	>5
<b>1240 to 1800</b>	>10:45		>8:15	>6	>4:30

**Note:** SB900-series batteries use SBC200, SBC800 and SBC220 chargers.

The values in this table are typical of fresh, high quality batteries. Battery runtime varies depending on the manufacturer and age of the battery.

## Frequency Range and Transmitter Output Power

Band	Frequency Range ( MHz )	Power delivered to antenna port ( mW RMS ) (Lo/Nm/Hi)
<b>G50</b>	470 to 534	1/10/20
<b>G51</b>	470 to 534	1/10/20
<b>G52</b>	479 to 534	1/10
<b>G53</b>	470 to 510	1/10/20
<b>G54*</b>	479 to 565	1/10/20
<b>G55*†</b>	470 to 608, 614 to 636	1/10/20
<b>G56*</b>	470 to 636	1/10/20
<b>G57*</b>	470 to 608	1/10/20
<b>G62</b>	510 to 530	1/10/20
<b>G65*</b>	470 to 606	1/10/20
<b>G66*</b>	487 to 606	1/10
<b>H50</b>	534 to 598	1/10/20
<b>H51</b>	534 to 598	1/10/20
<b>H52</b>	534 to 565	1/10
<b>H54*</b>	520 to 636	1/10/20

Band	Frequency Range ( MHz )	Power delivered to antenna port ( mW RMS ) (Lo/Nm/Hi)
<b>J50</b>	572 to 636	1/10/20
<b>J50A Δ</b>	572 to 608	1/10/20
<b>J51</b>	572 to 636	1/10/20
<b>K51</b>	606 to 670	1/10
<b>L50</b>	632 to 696	1/10/20
<b>L51</b>	632 to 696	1/10/20
<b>L53</b>	632 to 714	1/10/20
<b>M19</b>	694 to 703	1/10/20
<b>P51</b>	710 to 782	1/10/20
<b>R51</b>	800 to 810	1/10/20
<b>JB (Tx only)</b>	806 to 810	1/10
<b>AB (Rx and Tx)</b>	770 to 810	A Band (770-805): 1/10/20
		<b>B Band (806-809): 1/10</b>
<b>Q12</b>	748 to 758	1/10/20
<b>Q51</b>	794 to 806	10
<b>V50</b>	174 to 216	1/10/20
<b>V51</b>	174 to 216	1/10/20
<b>V52</b>	174 to 210	10
<b>X50</b>	925 to 932	1/10
<b>X51</b>	925 to 937.5	10
<b>X52</b>	902 to 928	0.25/10/20
<b>X53</b>	902 to 907.500, 915 to 928	0.25/10/20
<b>X54</b>	915 to 928	0.25/10/20
<b>Z16</b>	1240 to 1260	1/10/20
<b>Z17</b>	1492 to 1525	1/10/20
<b>Z18</b>	1785 to 1805	1/10/20
<b>Z19</b>	1785 to 1800	1/10/20
<b>Z20</b>	1790 to 1805	1/10/20

\*Supported by ULXD1, ULXD2, ULXD4D, and ULXD4Q only

†Operation mode varies according to region. The maximum power level for Peru is 10mW.

△ Output power limited to 10 mW above 608 MHz.

**Note:** Frequency bands might not be available for sale or authorized for use in all countries or regions.

The band Z17 (1492-1525 MHz) must be used indoors only.

For the Band Z19 (1785-1800MHz) used in Australia, per Radio Communications Low Interference Potential Devices Class License 2015; item 30 note C: the system must be operated within the range of 1790-1800MHz when used outdoors.

## Regulatory Information for Wireless Products Utilizing TV Frequency Bands

### G51 470-534 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
A, B, BG, CH, CY, CZ, D, DK, EST, F	*
FIN, GB, GR, H, HR, I, IRL, IS, L, LT	*
M, N, NL, P, PL, RO, S, SK, SLO, TR	*
All other countries	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

### G56 470-636 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
A, B, BG, CH, CY, CZ, D, DK, EST, F	*
FIN, GB, GR, H, HR, I, IRL, IS, L, LT	*
M, N, NL, P, PL, RO, S, SK, SLO, TR	*

Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
all other countries	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## H51 534-598 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
A, B, BG, CH, CY, CZ, D, EST	534 - 598 MHz*
F, GB, GR, H, I, IS, L, LT	534 - 598 MHz*
NL, P, PL, S, SK, SLO	534 - 598 MHz*
DK, FIN, M, N	*
HR, E, IRL, LV, RO, TR	*
All other countries	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## K51 606-670 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>A, B, BG, CH, CY, CZ, D, EST</b>	606 - 670 MHz*
<b>F, GB, GR, H, I, IS, L, LT</b>	606 - 670 MHz*
<b>NL, P, PL, S, SK, SLO</b>	606 - 670 MHz*
<b>RO</b>	646 - 647; 654 - 655; 662 - 663 MHz*
<b>DK, E, FIN, HR, IRL, LV, M, N, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## L52 632-694 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>A, B, BG, CH, CY, CZ, D, DK, EST, F</b>	*
<b>FIN, GB, GR, H, HR, I, IRL, IS, L, LT</b>	*
<b>M, N, NL, P, PL, RO, S, SK, SLO, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## P51 710-782 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>A, B, BG, CH, CY, CZ, D, EST, F, GB</b>	710 - 782 MHz*
<b>GR, H, I, IS, L, LT, NL, P, PL, S, SK, SLO</b>	710 - 782 MHz*
<b>RO</b>	718 - 719; 726 - 727; 734 - 743; 750 - 751; 758 - 759 MHz*
<b>DK, E, FIN, HR, IRL, LV, M, N, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## Q51 794-806 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>A, B, BG, CH, CY, CZ, D, DK, E, EST</b>	*
<b>F, FIN, GB, GR, H, HR, I, IRL, IS, L, LT</b>	*
<b>LV, M, N, NL, P, PL, S, SK, SLO, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## R51 800-810 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>N</b>	800 - 810 MHz*
<b>A, B, BG, CH, CY, CZ, D, DK, E, EST</b>	*
<b>F, FIN, GB, GR, H, HR, I, IRL, IS, L, LT</b>	*
<b>LV, M, N, NL, P, PL, S, SK, SLO, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## S50 823-832 MHz, 863-865 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>D</b>	license free
<b>A, B, BG, CH, CY, CZ, D, DK, EST, F</b>	*
<b>FIN, GB, GR, H, HR, I, IRL, IS, L, LT</b>	*
<b>M, N, NL, P, PL, RO, S, SK, SLO, TR</b>	*
<b>863 - 865 MHz</b>	EU: license free
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## V51 174-216 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
A, B, BG, CH, CY, CZ, D, DK, E, EST	*
F, FIN, GB, GR, H, HR, I, IRL, IS, L, LT	*
LV, M, N, NL, P, PL, S, SK, SLO, TR	*
All other countries	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## Z17 1492-1525 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
A, B, BG, CH, CY, CZ, D, DK, E, EST	*
F, FIN, GB, GR, H, HR, I, IRL, IS, L, LT	*
LV, M, N, NL, P, PL, S, SK, SLO, TR	*
<b>This Wireless microphone operates on the range of 1492-1525 MHz. Should be used INDOORS ONLY.</b>	
All other countries	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## Z18 1785-1805 MHz



Country Code	Frequency Range
Code de Pays	Gamme de fréquences
Codice di paese	Gamme di frequenza
Código de país	Gama de frecuencias
Länder-Kürzel	Frequenzbereich
<b>A, B, BG, CH, CY, CZ, D, DK, E, EST</b>	*
<b>F, FIN, GB, GR, H, HR, I, IRL, IS, L, LT</b>	*
<b>LV, M, N, NL, P, PL, S, SK, SLO, TR</b>	*
<b>All other countries</b>	*

\* This equipment may be capable of operating on some frequencies not authorized in your region. See [Licensing Information](#).

## Safety and Regulatory Information for Wireless Products

### Explanation of Symbols

	This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.
	This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

## Important Safety Instructions

1. READ these instructions.
2. KEEP these instructions.
3. HEED all warnings.
4. FOLLOW all instructions.
5. DO NOT use this apparatus near water.
6. CLEAN ONLY with dry cloth.
7. DO NOT block any ventilation openings. Allow sufficient distances for adequate ventilation and install in accordance with the manufacturer's instructions.
8. DO NOT install near any heat sources such as open flames, radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not place any open flame sources on the product.
9. DO NOT defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. PROTECT the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. ONLY USE attachments/accessories specified by the manufacturer.
12. USE only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. UNPLUG this apparatus during lightning storms or when unused for long periods of time.
14. REFER all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. DO NOT expose the apparatus to dripping and splashing. DO NOT put objects filled with liquids, such as vases, on the apparatus.
16. The MAINS plug or an appliance coupler shall remain readily operable.
17. The airborne noise of the Apparatus does not exceed 70dB (A).
18. Apparatus with CLASS I construction shall be connected to a MAINS socket outlet with a protective earthing connection.
19. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
20. Do not attempt to modify this product. Doing so could result in personal injury and/or product failure.
21. Operate this product within its specified operating temperature range.
22. Follow local regulations and consult qualified personnel if the product installation or relocation requires construction work. Choose mounting hardware and an installation location that can support the weight of the product. Avoid locations subject to constant vibration. Use the required tools to install the product properly. Inspect the product periodically.

**WARNING:**

- Voltages in this equipment are hazardous to life. No user-serviceable parts inside. Refer all servicing to qualified service personnel. The safety certifications do not apply when the operating voltage is changed from the factory setting.
- If water or other foreign objects enter the inside of the device, fire or electric shock may result.

## Safety Information for Batteries

1. Battery packs may explode or release toxic materials. Risk of fire or burns. Do not open, crush, modify, disassemble, heat above 140°F (60°C), or incinerate.
2. Follow instructions from manufacturer
3. Only use Shure charger to recharge Shure rechargeable batteries

**WARNING:**



Danger of explosion if battery incorrectly replaced. Replace only with same or equivalent type.

Do not dispose of the battery along with household waste. Check with local vendor for proper disposal of used battery packs.

4. Never put batteries in mouth. If swallowed, contact your physician or local poison control center
5. In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
6. Do not short circuit; may cause burns or catch fire
7. Do not charge or use battery packs other than Shure rechargeable batteries
8. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like
9. Do not immerse the battery in liquid such as water, beverages, or other fluids.
10. Do not attach or insert battery with polarity reversed.

11. Keep away from small children.
12. Do not use abnormal batteries.
13. Pack the battery securely for transport.

**Note:** Use only with the included power supply, batteries, or a Shure-approved equivalent.

## Storing Batteries

If batteries are to be stored for more than eight days, they should be placed into a temperature controlled storage area. Recommended battery storage temperature is 10 to 25°C (50 to 77°F).

Additional battery storage information is available at [shure.com/battery-storage](http://shure.com/battery-storage).



## Regulatory Information for Class B EMC Products

### CE Notice

Hereby, Shure Incorporated declares that this product with CE Marking has been determined to be in compliance with European Union requirements.

The full text of the EU declaration of conformity is available at the following site: <https://www.shure.com/en-EU/support/declarations-of-conformity>.

### UKCA Notice

Hereby, Shure Incorporated declares that this product with UKCA Marking has been determined to be in compliance with UKCA requirements.

The full text of the UK declaration of conformity is available at the following site: <https://www.shure.com/en-GB/support/declarations-of-conformity>.

## Cybersecurity STATEMENT OF COMPLIANCE

**Product Type:** Relevant connectable products defined as internet-connectable products or network-connectable products, in line with *inter alia* Product Security and Telecommunications Infrastructure Act 2022.

**Manufacturer Statement:** We, Shure Incorporated, certify and declare as manufacturer under our sole responsibility, that the above-mentioned product(s) conform(s) to the legislation as mentioned under Attachment 1 – to Cybersecurity Statement of Compliance listed here: <https://www.shure.com/en-GB/about-us/security>.

**Information on how to report security issues:** The latest version of Shure's Disclosure policy can be found at the following link: <https://www.shure.com/en-GB/about-us/security>

**Security update periods:** Shure provides support regarding hardware and software updates that continue the integral cyber security safety of Shure products up to 24 months after end of life (AEOL). For the full statement regarding Shure's product support policy, and information regarding products end of life status information can be found at the following link: <https://www.shure.com/en-GB/about-us/security>

**Manufacturer:**

Shure Incorporated 5800 Touhy Avenue  
Niles, Illinois, 60714-4608 U.S.A. Website: [www.Shure.com](http://www.Shure.com).

**Technical documentation is kept at:**

Shure Incorporated, Corporate Global Compliance Engineering Division

**UK Importer/Representative:**

Shure UK Limited  
Unit 2, The IO Centre, Lea Road, Waltham Abbey, Essex, EN9 1AS, U.K.  
Phone: +44 (0)1992 - 703058  
Email: EMEAsupport@shure.de

**On behalf of Manufacturer:**

Chad Ayers  
08 May 2025 Niles, Illinois  
Senior Director, Global Compliance

## FCC Notice

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference with radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the antenna of the radio/television receiver.
- Increase the separation between this equipment and the radio/television receiver.
- Plug the equipment into a different outlet so that the equipment and the radio/television receiver are on different power mains branch circuits.
- Consult a representative of Shure or an experienced radio/television technician for additional suggestions.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

**Notice:** The FCC regulations provide that changes or modifications not expressly approved by Shure Incorporated could void your authority to operate this equipment.

For information regarding responsible party and other matters relating to FCC compliance, please contact Shure Incorporated, 5800 W. Touhy Avenue, Niles, Illinois 60714-4608 U.S.A. [shure.com/contact](http://shure.com/contact)

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Canada, ISED Notice

**Notice:** The Industry Canada regulations provide that changes or modifications not expressly approved by Shure Inc. could void your authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body/head. This equipment should be installed and operated with minimum distance 0 cm between the radiator and your body/head.

## Canada Warning for Wireless

This device operates on a no-protection, no-interference basis. Should the user seek to obtain protection from other radio services operating in the same TV bands, a radio licence is required. For further details, consult Innovation, Science and Economic Development Canada's document Client Procedures Circular CPC-2-1-28, Voluntary Licensing of Licence-Exempt Low-Power Radio Apparatus in the TV Bands.

Ce dispositif fonctionne selon un régime de non.brouillage et de non.protection. Si l'utilisateur devait chercher à obtenir une certaine protection contre d'autres services radio fonctionnant dans les mêmes bandes de télévision, une licence radio serait requise. Pour en savoir plus, veuillez consulter la Circulaire des procédures concernant les clients CPC.2.1.28, Délivrance de licences sur une base volontaire pour les appareils radio de faible puissance exempts de licence et exploités dans les bandes de télévision d'Innovation, Sciences et Développement économique Canada.

## Industry Canada (IC) Notices

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The antenna(s) must be installed such that a minimum separation distance of 20 cm is maintained between the radiator (antenna) and all persons at all times.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. La ou les antennes doivent être installées de telle façon qu'une distance de séparation minimum de 20 cm soit maintenue entre le radiateur (antenne) et toute personne à tout moment.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment could be installed and operated with minimum distance 0 cm between the radiator and your body. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body/head.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement peut-être installé et utilisé avec une distance minimale de 0 cm entre le radiateur et votre corps. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE. Ces exigences un SAR limite de 1,6 W/kg en moyenne pour un gramme de tissu. La valeur SAR la plus élevée signalée en vertu de cette norme lors de la certification de produit à utiliser lorsqu'il est correctement porté sur les corps/ tête.

Additional Canadian information on RF exposure also can be found at the following Web address: <http://www.ic.gc.ca/eic/site/smt-gst.nsf/eng/sf08792.html>

## ACMA Notice

WARNING: This device operates under an ACMA class license and must comply with all conditions of that license including operating frequencies.

## ANATEL Notice

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados. Para maiores informações, consulte o site da ANATEL – <http://www.anatel.gov.br>.

## IFETEL Notice

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

## KCC Notice

해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없음

## NCC Notice

Connection and use of this communications equipment is permitted by the Nigerian Communications Commission.

## NCC Notice

### 低功率射頻器材技術規範

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

614MHz-703MHz: 使用頻段供其他通訊業務使用時，器材應即停止使用

## SRRC Notice

- (一) 本产品符合“微功率短距离无线电发射设备目录和技术要求”的具体条款和使用场景；
- (二) 不得擅自改变使用场景或使用条件、扩大发射频率范围、加大发射功率（包括额外加装射频功率放大器），不得擅自更改发射天线；
- (三) 不得对其他合法的无线电台（站）产生有害干扰，也不得提出免受有害干扰保护；
- (四) 应当承受辐射射频能量的工业、科学及医疗（ISM）应用设备的干扰或其他合法的无线电台（站）干扰；
- (五) 如对其他合法的无线电台（站）产生有害干扰时，应立即停止使用，并采取措施消除干扰后方可继续使用；
- (六) 在航空器内和依据法律法规、国家有关规定、标准划设的射电天文台、气象雷达站、卫星地球站（含测控、测距、接收、导航站）等军民用无线电台（站）、机场等的电磁环境保护区域内使用微功率设备，应当遵守电磁环境保护及相关行业主管部门的规定。

## Environmental Regulatory Information

### Waste Electrical and Electronic Equipment (WEEE) Directive



In the European Union and the United Kingdom, this label indicates that this product should not be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recycling.

### Registration, Evaluation, Authorization of Chemicals (REACH) Directive

REACH (Registration, Evaluation, Authorization of Chemicals) is the European Union (EU) and the United Kingdom (UK) chemical substances regulatory framework. Information on substances of very high concern contained in Shure products in a concentration above 0.1% weight over weight (w/w) is available upon request.

### Recycling Information

Please consider the environment, electric products and packaging are part of regional recycling schemes and do not belong to regular household waste.

# 中国 RoHS

部件名称	有害物质									
	Pb	Cd	Hg	Cr(VI)	PBB	PBDE	DBP	BBP	DIBP	DEHP
电路模块	X	○	○	○	○	○	○	○	○	○
金属模块	X	○	○	○	○	○	○	○	○	○
线缆及其组件	X	○	○	○	○	○	○	○	○	○
电源适配器*	X	○	○	○	○	○	○	○	○	○
锂电池组*	X	○	○	○	○	○	○	○	○	○

注1: ○: 表示该有害物质在该部件所有均质材料中的含量均不超出电器电子产品有害物质限制使用国家标准要求。  
 X: 表示该有害物质至少在该部件某一均质材料中的含量超出电器电子产品有害物质限制使用国家标准要求。  
 注2: 本产品大部分的部件采用无害的环保材料制造,含有有害物质的部件皆因全球技术发展水平的限制而无法实现有害物质的替代。  
 注3: 以上未列出的部分,表明其有害物质含量均不超出电器电子产品有害物质限制使用国家标准要求  
 \* 表示如果包含部分

## Certifications

### ULXD1, ULXD2

**IC:** 616A-ULXD1 G50, 616A-ULXD1 H50, 616A-ULXD1 J50, 616A-ULXD1 L50; 616A-ULXD2 G50, 616A-ULXD2 H50, 616A-ULXD2 J50, 616A-ULXD2 L50, 616A-ULXD1G50S, 616A-ULXD1H50S, 616A-ULXD1J50AS, 616A-ULXD2G50S, 616A-ULXD2H50S, 616A-ULXD2J50AS, 616A-ULXD1G57, 616A-ULXD2G57.

**FCC:** DD4ULXD1G50, DD4ULXD1H50, DD4ULXD1J50, DD4ULXD1L50; DD4ULXD2G50, DD4ULXD2H50, DD4ULXD2J50, DD4ULXD2L50, DD4ULXD1-G50, DD4ULXD1-H50, DD4ULXD1-J50A, DD4ULXD1-X52, DD4ULXD2-G50, DD4ULXD2-H50, DD4ULXD2-J50A, DD4ULXD2-X52, DD4ULXD1G57, DD4ULXD2G57 .

**IC:** 616A-ULXD1X52, 616A-ULXD2X52

**FCC:** DD4ULXD1X52, DD4ULXD2X52

**IC:** 616A-ULXD1V50, 616A-ULXD2V50

**FCC:** DD4ULXD1V50, DD4ULXD2V50

**Note:** For transmitters operating in the V50 and V51 bands: nominal free space antenna gain at middle of the band is typically -6 dBi, and rolls off at the band edges an additional -4 dB.